



NO DRY GRASS OR WEEDS


PRE-LAUNCH CHECK For safety, never launch a damaged rocket. Check the rocket's body, nose cone and fins. Also, check the engine mount, recovery system and launch lug(s). Repair any damage before launching the rocket.

FLYING YOUR ROCKET Choose a large field (500 ft. [152 m] square) free of dry weeds and brown grass. The larger the launch area, the better your chance of recovering your rocket. Football fields and playgrounds are great. Launch only with little or no wind and good visibility. Always follow the National Association of Rocketry (NAR) SAFETY CODE. MISFIRES TAKE THE KEY OUT OF THE CONTROLLER, WAIT ONE MINUTE BEFORE GOING NEAR THE ROCKET! Disconnect the igniter clips and remove the engine. Take the plug and igniter out of the engine. If the igniter has burned, it worked but did not ignite the engine because it was not touching the propellant inside the engine. Put a new igniter all the way inside the engine without bending it. Push the plug in place. Repeat the steps under Countdown and Launch.



© 2019 Estes Industries, LLC, All rights reserved. Estes Industries, LLC, 1295 H Street, Penrose, CO 81240-9698 Made in Guangdong, China

PN 090004-7280 (5-19)



IMPORTANT: Please record date found on decal and keep for future reference.

Read all instructions. Make sure you have all parts and supplies. Test fit all parts before applying glue. Product color and shape may vary.
























Alignment A 039290 066224 Body tube 090051-7280A Laser cut wood sheet 090051-7280B Laser cut wood sheet Laser cut wood sheet S 038190 Launch lug R 072601 Nose cone insert **B** 030222-4 Yellow Engine block T 063484 P 035002 Q 072609 Yellow spacer tool 038175 Launch lug 090001-7280 Waterslide decal (not shown) M 038366 2 N 038275 X 085704














SHOCK CORD MOUNT























Blot with clean paper towel. Let set overnight.
OPTIONAL: Apply protective clear coat.